



<sup>1</sup> Allow a minimum of  $\frac{1}{16}$ " gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

<sup>2</sup> Trusscore Wall&CeilingBoard installed vertically.

**NOTES:**

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. For steel studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



|                           |
|---------------------------|
| SCALE: 1-1/2" = 1'-0"     |
| REVISION DATE: 2024-02-16 |
| DRAWING: C4               |

FLOOR TO WALL, WALL TO CEILING - ROUNDED CORNER  
 2X4,6,8,10... STEEL STUD  
 VERTICAL PANEL INSTALLATION