



<sup>1</sup> Allow a minimum of  $\frac{1}{16}$ " gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

<sup>2</sup> Trusscore Wall&CeilingBoard installed vertically. .

<sup>3</sup> Outside Corner Square trim is intended to be adhered to Wall&CeilingBoard with a one-part, neutral cure silicone sealant.

NOTES:

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. For wood studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard

**trusscore**  
material + science

SCALE: 2" = 1'-0"

REVISION DATE: 2024-02-21

DRAWING: E1

OUTSIDE CORNER DETAIL - ROUNDED & SQUARE CORNERS  
2x4,6,8,10... WOOD STUD  
VERTICAL PANEL INSTALLATION