



¹ Allow a minimum of $\frac{1}{16}$ " gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

² Trusscore Wall&CeilingBoard installed horizontally.

NOTES:

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of $\frac{3}{8}$ ".
- Depending on your wall assembly, we recommend different types of screws. For a concrete wall assembly, use $\frac{3}{16}$ " x 1- $\frac{1}{4}$ " Flathead head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



SCALE: 1-1/2" = 1'-0"

REVISION DATE: 2024-02-21

DRAWING: F7

FLOOR TO WALL, WALL TO CEILING - SQUARE CORNER
 CONCRETE MASONRY UNIT (CMU)
 HORIZONTAL PANEL INSTALLATION