



¹ Allow a minimum of 1/16" gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

² Trusscore Wall&CeilingBoard installed horizontally.

NOTES:

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. For wood studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



SCALE: 1-1/2" = 1'-0"
REVISION DATE: 2024-02-21
DRAWING: G2

FLOOR TO WALL, WALL TO CEILING - ROUNDED CORNER
 2X4,6,8,10...WOOD STUD INSULATION
 HORIZONTAL PANEL INSTALLATION